

The prerequisites for the Top Kill Operation are:

- (1) 18" Casing cemented in place on the MC252 #3 Relief well.
- (2) Continuous subsea dispersant application in place to mitigate. VoCs around the Top Kill Operation vessels.
- (3) Procedures and Equipment in place ready to remove the riser from the top of the Deepwater Horizon BOP.
- (4) Transocean Development Driller II ready to run their BOP on top of the Deepwater Horizon BOP.
- (5) Ability to monitor the subsea pressures at the choke and kill lines as well as at the base of the Deepwater Horizon BOP stack.