
11305.2.8



So it is time to move on to the next option, which is to put a cap on top of the BOP to contain the spill and pump it to the surface.

TREX 011305.0002

that BP is making at every step.